



## ALLOY WHEEL RIM PROTECTORS

### Fitting Instructions

- 1) Using IPA cleaning wipes provided-clean alloy wheel rims.
- 2) Using primer wipes provided-thoroughly coat wheel rims.
  - 3) Allow primer to dry for 5 minutes.
- 4) Remove backing tape and apply Scuffs.
- 5) Mark with a pencil and cut where ends meet.
- 6) Apply very firm pressure to ensure Scuffs have bonded.
- 7) Let tape bond for 24 hours before driving above 40mph.

Wash hands thoroughly after handling wipes included in kit or wear latex gloves.

Do not fit in cold or damp conditions.

Any primer residue left on wheels can be removed with IPA wipes.

Balance weights need to be fitted inside the wheels and removed from lip.

Scuffs will not stick to wheels coated in low surface energy coatings and cleaners.

Scuffs will not stick to silicone residue left on wheels from cleaning solutions.

Inspect on a regular basis and replace if damaged.