



JR3B-6540544-A 2018+ MUSTANG GT 1-PIECE REAR DIFFUSER

Installation Instructions for 2018 Ford Mustang GT

WARNING!

If any part of this installation seems beyond your level of installation experience, please seek the help of a certified professional.

Before installing this Drake Muscle Cars product, please read through the installation procedure and verify that all parts are present, including the supplied hardware. If any items are missing, please contact Drake Muscle Cars at (702) 853-2060, 8:00 AM to 5:00 PM PST.

KIT INCLUDES

- 1 Rear Diffuser
- 2 Mounting Brackets
- 4 Bolts (6mm x 12)
- 4 Nuts (6mm)
- 4 Bolts (6mm x 16)
- 16 Washers
- 4 Self-Drilling Screws

TOOLS NEEDED FOR INSTALLATION

- Phillips Head Screwdriver
- Plastic Panel Removal Tool
- 10mm Socket
- 1/4" or 3/8" Drive Ratchet

INSTALLATION

1. Support the rear of the vehicle on jack stands or place the vehicle on a lift to ensure ample working space. Allow time for the vehicle to cool as you will be working near the exhaust system.
2. On a clean, flat surface, bolt the two (2) supplied brackets onto the diffuser using the supplied short 6mm x12 bolts and washers. (*figure 1*)
3. Locate and remove the four (4) plastic push pins on either side of the rear fascia using a plastic panel removal tool or a thin flat-headed screwdriver. These pins can be found just to the outside of each of the vehicle's mufflers. (*figure 2*)
4. Once removed, place the four 6mm x16 bolts and washers through the slots from the top. (*figure 3*)



Figure 1



Figure 2



Figure 3



JR3B-6540544-A
2018+ MUSTANG GT 1-PIECE REAR DIFFUSER

Installation Instructions for 2018 Ford Mustang GT

WARNING!

If any part of this installation seems beyond your level of installation experience, please seek the help of a certified professional.

INSTALLATION

5. Bring the assembled diffuser up to meet the bolts and thread the nuts with washers onto the bolts.
6. With the diffuser loosely in place, line up the recesses in the top of the diffuser to the fins on the factory lower valance. While firmly holding the diffuser in place, carefully install the supplied self-drilling screws and washers. (*figure 4*)
7. Tighten the outer hardware to 10ft-lbs to finalize the installation. (*figure 4*)

Note: Ensure ample clearance around exhaust tips.
This part is designed for vehicles with up to 4" exhaust tips.



Figure 4



Figure 5

Drake Muscle Cars

130 Cassia Way, Henderson, NV 89014-6615

Tel: (702) 853-2060 Fax: (702) 853-2061

www.DrakeMuscleCars.com