



## INSTALLATION INSTRUCTIONS

Holley Vintage Series Cast Aluminum Oval Air Cleaner Assembly with 4bbl Baseplate  
P/N's 120-400 through 120-404

---

- 1.) Remove any stock or existing air cleaner components. It is recommended to plug the throttle body / carburetor bores to ensure that nothing can fall into them during installation.
- 2.) Place the supplied air cleaner gasket (replacement Holley P/N 108-4) onto the mounting flange.
- 3.) Install the air cleaner mounting stud into the threaded hole on top of your throttle body / carburetor, followed by the stamped oval baseplate and filter element. Ensure that the baseplate is resting firmly on the air cleaner gasket with no obstructions. Be sure to remove any bore plugs you inserted in Step 1 before mounting the stamped oval lid.

**WARNING! Inadequate clearance between the throttle lever and the air cleaner baseplate could result in uncontrolled engine speed.**

- 4.) Place the cast aluminum oval air cleaner lid onto the mounting stud and tighten it down securely using the supplied wing nut.
- 5.) Carefully check the hood clearance before closing the hood.

**Holley Technical Support**  
1801 Russellville Road  
Bowling Green, KY 42101  
270-781-9741 or 1-866-464-6553  
[www.holley.com](http://www.holley.com)

© 2020 Holley Performance Products. All Rights Reserved. Tous Droits Réservés.

**199R12033**  
**Date: 1-10-20**