



AMERICAN CAR CRAFT INSTRUCTIONS

CAMARO WIRE HARNESS COVER

PART #103036

Parts Included:

- 1x Wire Harness Cover
- 1x 3/8" Washer Head Screw
- 1x 1" Decorative Chrome Cap

Introduction: This new cover has been especially designed to install to the 2010 Camaro LS3 engine very easily. An ACC wire tuck is required.

Liner Information: Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation.

1. After you have performed the ACC wire tuck procedure you should have all the wires stranded along the front side of the factory valve cover thus the need for this unique cover. . This newly created wire cover will slip over a single wire cable running over to the throttle body as it covers over the larger harness tract created during the tuck procedure. The new cover will have a long slit specifically for this wire.
2. Before you attempt to slide the new cover in place you will have the large bolt and loop securing the harness protruding from the left side of the engine headed directly towards the front of the vehicle. This bolt will need to be taped in order to create the single attachment screw needed for this installation. Using a 5/32 cobalt drill bit, drill the dead center of the bolt head inward about 1/2". Then using the 3/8 washer head screw provided drive the screw into your newly created hole to create a threaded hole specifically for your new screw. Once threaded, remove the screw. This screw will be the only necessary attachment point for the new cover.
3. Slip the new cover over the single wire harness running over to the throttle body and then jostle the new cover in position so the hole on the cover lines up with the hole you just piloted. Then simply set the screw in place to secure the new cover. You have been provided with a 1" decorative chrome cap. Using clear 100% silicone, apply a small dab of the silicone to the underside of the cap and set it over your screw. Use a small piece of masking tape to hold the new cap in place until the silicone sets in about 3 hours. That will complete the installation.